A Keyword Spotting Model













A model for **Keyword Spotting**



A model for **Keyword Spotting**



Can we use the same model we used in *Course 1* for Horses v. Humans?

```
model = tf.keras.models.Sequential([
   # Five convolutional + pooling layers to extract features
   tf.keras.layers.Conv2D(16, (3,3), activation='relu', input_shape=(300, 300, 3)),
   tf.keras.layers.MaxPooling2D(2, 2),
   tf.keras.layers.Conv2D(32, (3,3), activation='relu'),
   tf.keras.layers.MaxPooling2D(2,2),
   tf.keras.layers.Conv2D(64, (3,3), activation='relu'),
   tf.keras.layers.MaxPooling2D(2,2),
   tf.keras.layers.Conv2D(64, (3,3), activation='relu'),
   tf.keras.layers.MaxPooling2D(2,2),
   tf.keras.layers.Conv2D(64, (3,3), activation='relu'),
   tf.keras.layers.MaxPooling2D(2,2),
   # Flatten the results to feed into a DNN and classify
   tf.keras.layers.Flatten(),
   tf.keras.layers.Dense(512, activation='relu'),
   tf.keras.layers.Dense(1, activation='sigmoid')
```



Convert the model to TFLite and print the size tf.saved_model.save(model, SAVED_MODEL) float_converter = tf.lite.TFLiteConverter.from_saved_model(SAVED_MODEL) float_tflite_model = float_converter.convert()

float_tflite_model_size = open(FLOAT_MODEL_TFLITE, "wb").write(float_tflite_model)



Our board [Course 3 Kit] only has 256KB of RAM (memory)

print("Float model is %d bytes" % float_tflite_model_size)

Convert the model to TFLite and print the size

```
tf.saved_model.save(model, SAVED_MODEL)
float_converter = tf.lite.TFLiteConverter.from_saved_model(SAVED_MODEL)
float_tflite_model = float_converter.convert()
float_tflite_model_size = open(FLOAT_MODEL_TFLITE, "wb").write(float_tflite_model)
print("Float model is %d bytes" % float_tflite_model_size)
```

6822684 bytes ~ 6,800 KB



Quantize the model and print the size

```
converter = tf.lite.TFLiteConverter.from_saved_model(SAVED_MODEL)
converter.optimizations = [tf.lite.Optimize.DEFAULT] # INT8 Quantization
converter.representative_dataset = representative_data_gen # extract test dataset
tflite_model = converter.convert()
tflite_model_size = open(MODEL_TFLITE, "wb").write(tflite_model)
print("Quantized model is %d bytes" % tflite_model_size)
```



Quantize the model and print the size

```
converter = tf.lite.TFLiteConverter.from_saved_model(SAVED_MODEL)
converter.optimizations = [tf.lite.Optimize.DEFAULT] # INT8 Quantization
converter.representative_dataset = representative_data_gen # extract test dataset
tflite_model = converter.convert()
tflite_model_size = open(MODEL_TFLITE, "wb").write(tflite_model)
print("Quantized model is %d bytes" % tflite_model_size)
```

1722272 bytes ~ 1,700 KB



```
# Quantize the model and print the size
converter = tf.lite.TFLiteConverter.from_saved_model(SAVED_MODEL)
converter.optimizations = [tf.lite.Optimize.DEFAULT] # INT8 Quantization
converter.representative_dataset = representative_data_gen # extract test dataset
tflite_model = converter.convert()
tflite_model_size = open(MODEL_TFLITE, "wb").write(tflite_model)
print("Quantized model is %d bytes" % tflite_model_size)
```


NEED SMALLER MODEL




TinyConv Model

One Conv2D followed by a single Dense Layer!














One Conv2D followed by a single Dense Layer!

<70 KBs for float and only <17 KBs quantized



One Conv2D followed by a single Dense Layer!

FAST INFERENCE

<70 KBs for float and only <17 KBs quantized

